

Command List

The following table lists the set of commands and arguments supported by the receiver. A full description of the commands can be found in the Reference Guide. Note that, depending on the options enabled on your receiver, some commands may not be supported.

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
eawa gawa	exeAddWiFiAccessPoint getAddWiFiAccessPoint	SSID (32)	Key (40)							
sam gam	setAGCMode getAGCMode	Band Band	Mode auto frozen manual	Gain 0 ... <u>35</u> ... 70 dB						
lai	lstAntennaInfo	Antenna								
		Overview Main Aux1 [antenna name]								
sal gal	setAntennaLocation getAntennaLocation	Antenna Antenna	Mode auto manual	DeltaX -1000.0000 ... 0.0000 ... 1000.0000 m	DeltaY -1000.0000 ... 0.0000 ... 1000.0000 m	DeltaZ -1000.0000 ... 0.0000 ... 1000.0000 m				
sao gao	setAntennaOffset getAntennaOffset	Antenna Antenna	DeltaE -1000.0000 ... 0.0000 ... 1000.0000 m	DeltaN -1000.0000 ... 0.0000 ... 1000.0000 m	DeltaU -1000.0000 ... 0.0000 ... 1000.0000 m	Type (20) Unknown	SerialNr (20) Unknown	SetupID 0 ... 255		
sto gto	setAttitudeOffset getAttitudeOffset	Heading -360.000 ... 0.000 ... 360.000 deg	Pitch -90.000 ... 0.000 ... 90.000 deg							
stoa gtoa	setAttOffsetApplicability getAttOffsetApplicability	Messages								
		none + SBF + NMEA all								
sbbs gbbs	setBBSamplingMode getBBSamplingMode	Mode								
		BeforeIM AfterIM								
sbtP gbtP	setBTPParameters getBTPParameters	Enable	DeviceName (32)	PairingCode (8)	Discoverable	DeviceNameActu				
		off on	default	1234	off on	model-serialnumb				
sdc gcd	setCellularDataCall getCellularDataCall	Enable	Role	CallNumber (20)	Speed					

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		off on	Calling Accepting		auto V.32_auto V.34_9600baud V.34_14400baud V.110_auto V.110_14400baud V.120_auto V.120_14400baud					
scem gcem	setCellularParameters getCellularParameters	Power	Connect	APN (32)	User (32)	Password (40)	Standard			
		off on	off on				+ 2G + 3G + 4G all			
scep gccep	setCellularPIN getCellularPIN	PIN (20)								
eccp gccp	exeChangeCellularPIN getChangeCellularPIN	OldPIN (20)	NewPIN (20)							
sca gca	setChannelAllocation getChannelAllocation	Channel Channel	Satellite	Search	Doppler	Window				
		+ Ch01 ... Ch50 all	auto G01 ... G32 F01 ... F14 E01 ... E36 S120 ... S158 C01 ... C63 J01 ... J07 I01 ... I14	auto manual	-50000 ... 0 ...50000 Hz	1 ... 16000 ...100000 Hz				
gcc	getChannelConfiguration	Channel								
		+ Ch01 ... Ch50 all								
scia gcia	setCheckInternetAvailability getCheckInternetAvailability	Mode								
		off on								
scst gcst	setClockSyncThreshold getClockSyncThreshold	Threshold								
		ClockSteering usec500 msec1 msec2 msec3 msec4 msec5								
sc2f gc2f	setCMRv2Formatting getCMRv2Formatting	ReferenceID								
		0 ... 31								
sc2i gc2i	setCMRv2Interval getCMRv2Interval	Message Message	Interval							
		+ CMR0 + CMR1 + CMR2 + CMR3 all	0.1 ... 1.0 ...600.0 s							
sc2m gc2m	setCMRv2Message2 getCMRv2Message2	ShortID (8)	LongID (50)	COGO (16)						

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		<u>Unknown</u>	<u>Unknown</u>	<u>Unknown</u>						
sc2o gc2o	setCMRv2Output getCMRv2Output	Cd <i>Cd</i>	<i>Messages</i>							
		+ COM1 + COM2 + COM3 + USB1 + USB2 + IP10 ... IP17 + NTR1 + NTR2 + NTR3 + IPS1 + IPS2 + IPS3 + IPS4 + IPS5 + BT01 + UHF1 + IPR1 + IPR2 + IPR3 + IPR4 + IPR5 all	none + <u>CMR0</u> + <u>CMR1</u> + <u>CMR2</u> + <u>CMR3</u> all							
sc2u gc2u	setCMRv2Usage getCMRv2Usage	<i>MsgUsage</i>								
		none + <u>CMR0</u> + <u>CMR1</u> + <u>CMR2</u> + <u>CMR3</u> + <u>CMR0p</u> + <u>CMR0w</u> all								
scm gcm	setCN0Mask getCN0Mask	Signal <i>Signal</i>	<i>Mask</i>							
		+ GPSL1CA + Reserved1 + Reserved2 + GPSL2C + GPSL5 + GLOL1CA + GLOL2P + GLOL2CA + GALL1BC + GALE6BC + GALE5a + GALE5b + GALE5 + GEOL1 + GEOL5 + BDSB11 + BDSB21 + BDSB31 + BDSB1C + BDSB2a + BDSB2b + QZSL1CA + QZSL2C + QZSL5 + QZSL6 + NAVICL5 all	0 ... 10 ... 60 dB-Hz							
help	IstCommandHelp	Action (255)								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		Overview								
scs gcs	setCOMSettings getCOMSettings	Cd <i>Cd</i>	<i>Rate</i>	<i>DataBits</i>	<i>Parity</i>	<i>StopBits</i>	<i>FlowControl</i>			
		+ COM1 + COM2 + COM3 all	baud1200 baud2400 baud4800 baud9600 baud19200 baud38400 baud57600 <u>baud115200</u> baud230400 baud460800	<u>bits8</u>	<u>No</u>	<u>bit1</u>	none RTS CTS			
lcf	IstConfigFile	File								
		Current Boot RxDefault User1 User2								
eccf gccf	exeCopyConfigFile getCopyConfigFile	Source	Target							
		<u>Current</u> Boot User1 User2 RxDefault	<u>Current</u> Boot User1 User2							
scoc gcoc	setCosmosConfig getCosmosConfig	<i>Enable</i>	<i>CustomerID (24)</i>							
		<u>off</u> on								
soda gcda	setCrossDomainWebAccess getCrossDomainWebAccess	<i>Mode</i>								
		<u>off</u> on								
lcu	IstCurrentUser									
sdcn gdcn	setDaisyChainMode getDaisyChainMode	DC <i>DC</i>	<i>Mode</i>							
		+ DC1 + DC2 all	<u>Raw</u> ASCII							
sdio gdio	setDataInOut getDataInOut	Cd <i>Cd</i>	<i>Input</i>	<i>Output</i>	<i>Show</i>					

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ DSK1 + COM1 + COM2 + COM3 + USB1 + USB2 + IP10 ... IP17 + NTR1 + NTR2 + NTR3 + IPS1 + IPS2 + IPS3 + IPS4 + IPS5 + BT01 + UHF1 + IPR1 + IPR2 + IPR3 + IPR4 + IPR5 all	none CMD RTCMv2 RTCMv3 CMRv2 DC1 DC2 ASCIIN <u>auto</u>	none + RTCMv2 + RTCMv3 + CMRv2 + <u>SBF</u> + <u>NMEA</u> + ASCIIIDisplay + DC1 + DC2 + Encapsulate + LBandBeam1 + LBandBeam2	(off) (on) (waiting)					
sdal gdal	setDefaultAccessLevel getDefaultAccessLevel	<i>Web</i>	<i>FileTransfer</i>	<i>Ip</i>	<i>Com</i>	<i>Usb</i>	<i>Bt</i>			
		none Viewer <u>User</u>	none <u>Viewer</u> User	none Viewer <u>User</u>	none Viewer <u>User</u>	none Viewer <u>User</u>	none Viewer <u>User</u>			
sdca gdca	setDiffCorrMaxAge getDiffCorrMaxAge	<i>DGPSCorr</i>	<i>RTKCorr</i>	<i>PPPCorr</i>	<i>Iono</i>					
		0.0 ... <u>400.0</u> ...3600.0 s	0.0 ... <u>20.0</u> ...3600.0 s	<u>0.0</u> ...0.0 s	0.0 ... <u>600.0</u> ...3600.0 s					
sdcu gdcu	setDiffCorrUsage getDiffCorrUsage	<i>Mode</i>	<i>MaxAge</i>	<i>BaseSelection</i>	<i>BaseID</i>	<i>MovingBase</i>	<i>MaxBase</i>	<i>MaxBaseline</i>		
		<u>LowLatency</u>	0.1 ... <u>3600.0</u> s	<u>auto</u> manual	0 ...4095	<u>off</u> on	1 ...10	0 ... <u>2500000</u> m		
sdfa gdfa	setDiskFullAction getDiskFullAction	<i>Disk</i> <i>Disk</i>	<i>Action</i>							
		+ DSK1 all	DeleteOldest <u>StopLogging</u>							
ldi	lstDiskInfo	<i>Disk</i>	<i>Directory (60)</i>							
		DSK1 all								
sdds gdds	setDynamicDNS getDynamicDNS	<i>Provider</i>	<i>UserName (40)</i>	<i>Password (40)</i>	<i>Hostname (40)</i>	<i>Bind</i>				
		off dyndns.org no-ip.com				<u>auto</u> Ethernet WiFi Cell				
ecm gecm	exeEchoMessage getEchoMessage	<i>Cd</i>	<i>Message (242)</i>	<i>EndOfLine</i>						

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		DSK1 COM1 COM2 COM3 USB1 USB2 IP10 ... IP17 IPS1 IPS2 IPS3 IPS4 IPS5 BT01 UHF1 IPR1 IPR2 IPR3 IPR4 IPR5 DC1 DC2	<u>A:Unknown</u>	<u>none</u> + CR + LF all						
sem gem	setElevationMask getElevationMask	Engine <i>Engine</i>	<i>Mask</i>							
		+ Tracking + PVT all	-90 ... <u>0</u> ... 90 deg							
smth gmth	setENHTransfoHorizontal getENHTransfoHorizontal	TransfoID <i>TransfoID</i>	<i>DeltaE</i>	<i>DeltaN</i>	<i>E0</i>	<i>N0</i>	<i>AlphaEE</i>	<i>AlphaEN</i>	<i>AlphaNE</i>	<i>AlphaNN</i>
		+ It1 all	-250.0000 ... <u>0.0000</u> ... 250.0000 m	-250.0000 ... <u>0.0000</u> ... 250.0000 m	-8000000.0000 ... <u>0.0000</u> ... 8000000.0000 m	-8000000.0000 ... <u>0.0000</u> ... 8000000.0000 m	-1000.0000 ... <u>0.0000</u> ... 1000.0000 ppm	-1000.0000 ... <u>0.0000</u> ... 1000.0000 ppm	-1000.0000 ... <u>0.0000</u> ... 1000.0000 ppm	-1000.0000 ... <u>0.0000</u> ... 1000.0000 ppm
smtv gmtv	setENHTransfoVertical getENHTransfoVertical	TransfoID <i>TransfoID</i>	<i>DeltaH</i>	<i>E0</i>	<i>N0</i>	<i>AlphaHE</i>	<i>AlphaHN</i>			
		+ It1 all	-250.0000 ... <u>0.0000</u> ... 250.0000 m	-8000000.0000 ... <u>0.0000</u> ... 8000000.0000 m	-8000000.0000 ... <u>0.0000</u> ... 8000000.0000 m	-1000.0000 ... <u>0.0000</u> ... 1000.0000 ppm	-1000.0000 ... <u>0.0000</u> ... 1000.0000 ppm			
seth geth	setEthernetMode getEthernetMode	<i>Enable</i>								
		off <u>on</u>								
sep gep	setEventParameters getEventParameters	Event <i>Event</i>	<i>Polarity</i>	<i>Delay</i>						
		+ EventA + EventB all	Low2High High2Low	-500.000000 ... <u>0.000000</u> ... 500.000000 ms						
sfn gfn	setFileNaming getFileNaming	Cd <i>Cd</i>	<i>NamingType</i>	<i>FileName (20)</i>						
		+ DSK1 all	FileName Incremental IGS15M IGS1H IGS6H IGS24H	<u>log</u>						
sfr gfr	setFixReliability getFixReliability	Engine <i>Engine</i>	<i>SearchVolume</i>	<i>Ratio</i>						
		+ RTK + GNSSAttitude all	0.001 ... <u>0.200</u> ... 10.000	1.00 ... <u>4.40</u> ... 20.00						
sfm gfm	setFrontendMode getFrontendMode	<i>Mode</i>								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		Nominal SingleAnt								
sfpr gfpr	setFTPPushRINEX getFTPPushRINEX	Server (32)	Path (64)	User (12)	Password (24)					
				anonymous						
sfps gfps	setFTPPushSBF getFTPPushSBF	Server (32)	Path (64)	User (12)	Password (24)					
				anonymous						
efpt gfpt	exeFTPPushTest getFTPPushTest	Server (40)	Path (64)	User (20)	Password (40)					
				anonymous						
efup gfup	exeFTPUpgrade getFTPUpgrade	Server (32)	Path (64)	Login (12)	Password (24)					
				anonymous						
sgd ggd	setGeodeticDatum getGeodeticDatum	TargetDatum								
		WGS84 ETRS89 NAD83 NAD83_PA NAD83_MA GDA94 GDA2020 Default User1 User2								
sgu ggu	setGeoidUndulation getGeoidUndulation	Mode	Undulation							
		auto manual	-250.000 ... 0.000 ... 250.000 m							
sfno gfno	setGlobalFileNamingOptions getGlobalFileNamingOptions	BusyTag								
		off on								
sga gga	setGNSSAttitude getGNSSAttitude	Source	MultiAntennaMod							
		none MovingBase MultiAntenna	+ Float + Fixed							
sgpf ggpf	setGPIOFunctionality getGPIOFunctionality	GPPin GPPin	Mode	Input	Output					
		+ GP1 + GP2 + GP3 all	Output	none	LevelLow LevelHigh					
shm ghm	setHealthMask getHealthMask	Engine Engine	Mask							
		+ Tracking + PVT all	off on							
shs ghs	setHttpsSettings getHttpsSettings	Protocol								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ HTTP + HTTPS all								
lif	IstInternalFile	File								
		Permissions Identification Debug Error SisError DiffCorrError SetupError IPParameters RxMessages								
sim gim	setlonosphereModel getlonosphereModel	Model								
		auto off Klobuchar SBAS MultiFreq KlobucharBeiDou								
sipf gipf	setIPFiltering getIPFiltering	Mode	AddrList (200)							
		off on								
sipk gipk	setIPKeepAlive getIPKeepAlive	Enable	IdleTime	Interval	MaxCount					
		off on	15 ... 18000 s	1 ... 3600 s	1 ... 15 ... 3600					
sipp gipp	setIPPortSettings getIPPortSettings	Command	FTPControl							
		1 ... 28784 ... 65535	1 ... 21 ... 65535							
sirs girs	setIPReceiveSettings getIPReceiveSettings	Cd Cd	Port	Mode	TCPAddress (40)					
		+ IPR1 + IPR2 + IPR3 + IPR4 + IPR5 all	0 ... 65535	TCP2Way UDP	0.0.0.0					
sis giss	setIPServerSettings getIPServerSettings	Cd Cd	Port	Mode	UDPAddress (20)					
		+ IPS1 + IPS2 + IPS3 + IPS4 + IPS5 all	0 ... 65535	TCP UDP TCP2Way	255.255.255.255					
sips gips	setIPSettings getIPSettings	Mode	IP (16)	Netmask (16)	Gateway (16)	Domain (63)	DNS1 (16)	DNS2 (16)	MTU	
		DHCP Static	0.0.0.0	255.255.255.0	0.0.0.0		0.0.0.0	0.0.0.0	0 ... 1500	
scls gcls	setL6CLASSource getL6CLASSource	Satellite	Message							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		<u>auto</u> none J01 ... J07	<u>L6D</u> L6E							
llbb	IstLBandBeams									
slbb glbb	setLBandBeams getLBandBeams	Beam Beam	<i>Frequency</i>	<i>Rate</i>	<i>Name (8)</i>	<i>Region (8)</i>	<i>Usage</i>			
		+ User1 User16 all	... 1525000000 ... 1559000000 Hz	baud600 baud1200 baud2400 baud4800	<u>Unknown</u>	<u>Unknown</u>	<u>Disabled</u> Enabled			
slcs glcs	setLBandCustomServiceID getLBandCustomServiceID	<i>ServiceID (4)</i>	<i>ScramblingVector</i>	<i>NDAUsage</i>						
		<u>0000</u>	<u>0000</u>	<u>off</u> on						
slsm glsm	setLBandSelectMode getLBandSelectMode	<i>Mode</i>	<i>Service</i>	<i>Beam1</i>	<i>Beam2</i>					
		<u>off</u> manual	<u>LBAS1</u>	<u>User1</u> User2 ... User16	User1 <u>User2</u> User3 ... User16					
slm glm	setLEDMode getLEDMode	<i>GPLED</i>								
		<u>DIFFCORLED</u> PVTLED LOGLED								
slco glco	setLocalCoordOperation getLocalCoordOperation	<i>OpName (100)</i>	<i>ENHTransfo</i>							
		<u>NETWORK</u>	<u>none</u> lt1							
llc	IstLocalCoordOperations	Operation								
		Overview								
login	LogIn	<i>UserName (16)</i>	<i>Password (32)</i>							
logout	LogOut									
smv gmv	setMagneticVariance getMagneticVariance	<i>Mode</i>	<i>Variation</i>							
		<u>auto</u> manual	-180.0 ... <u>0.0</u> ... 180.0 deg							
emd gmd	exeManageDisk getManageDisk	Disk	Action							
		<u>DSK1</u>	<u>Unmount</u> Mount Format							
emwa gmwa	exeManageWiFiAccessPoint getManageWiFiAccessPoint	SSID (32)	Action							
			<u>Promote</u> Remove							
smp gmp	setMarkerParameters getMarkerParameters	<i>MarkerName (60)</i>	<i>MarkerNumber (20)</i>	<i>MarkerType (20)</i>	<i>StationCode (10)</i>	<i>MonumentIdx</i>	<i>ReceiverIdx</i>	<i>CountryCode (3)</i>		
		<u>SEPT</u>	<u>Unknown</u>	<u>Unknown</u>		<u>0 ... 9</u>	<u>0 ... 9</u>			
smrf gmrf	setMeas3MaxRefInterval getMeas3MaxRefInterval	<i>MaxIntrvl</i>								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		OnlyRef msec500 sec1 sec5 sec10 sec30 sec60								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
lmd	IstMIBDescription	<i>File (255)</i>								
		Overview SBFTable								
smm gmm	setMultipathMitigation getMultipathMitigation	<i>Code</i>	<i>Carrier</i>							
		off <u>on</u>	off <u>on</u>							
snc gnrc	setNetworkRTKConfig getNetworkRTKConfig	<i>NetworkType</i>								
		auto VRS								
enoc gnoc	exeNMEAOnce getNMEAOnce	<i>Cd</i>	<i>Messages</i>							
		DSK1 COM1 COM2 COM3 USB1 USB2 IP10 ... IP17 NTR1 NTR2 NTR3 IPS1 IPS2 IPS3 IPS4 IPS5 BT01 UHF1 IPR1 IPR2 IPR3 IPR4 IPR5	+ ALM + DTM + GBS + GGA + GLL + GNS + GRS + GSA + GST + GSV + HDT + RMC + ROT + VTG + ZDA + HRP + LLQ + RBP + RBV + RBD + AVR + GGAaux1 + GGK + GFA + GGQ + LLK + GMP + TFM + SNC + SCL + THS							
sno gno	setNMEAOutput getNMEAOutput	<i>Stream</i> <i>Stream</i>	<i>Cd</i>	<i>Messages</i>	<i>Interval</i>					

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ Stream1 Stream10 all	... <u>none</u> DSK1 COM1 COM2 COM3 USB1 USB2 IP10 ... IP17 NTR1 NTR2 NTR3 IPS1 IPS2 IPS3 IPS4 IPS5 BT01 UHF1 IPR1 IPR2 IPR3 IPR4 IPR5	<u>none</u> + ALM + DTM + GBS + GGA + GLL + GNS + GRS + GSA + GST + GSV + HDT + RMC + ROT + VTG + ZDA + HRP + LLQ + RBP + RBV + RBD + PUMRD + AVR + GGAaux1 + GGK + GFA + GGQ + LLK + GMP + TXTbase + TFM + SNC + SCL + THS	<u>off</u> OnChange msec10 msec20 msec40 msec50 msec100 msec200 msec500 sec1 sec2 sec5 sec10 sec15 sec30 sec60 min2 min5 min10 min15 min30 min60					
snp gnp	setNMEAPrecision getNMEAPrecision	<i>NrExtraDigits</i>	<i>Compatibility</i>	<i>LocalDatum</i>	<i>MinStdDev</i>					
		0 ... 3	Nominal Mode1 Mode2	<u>off</u> only	0.000 ... 0.001 ... 1.000 m					
snti gnti	setNMEATalkerID getNMEATalkerID	<i>TalkerID</i>								
		auto <u>GP</u> GN								
snv gnv	setNMEAVersion getNMEAVersion	<i>Version</i>								
		v3x v4x								
snf gnf	setNotchFiltering getNotchFiltering	Notch <i>Notch</i>	<i>Mode</i>	<i>CenterFreq</i>	<i>Bandwidth</i>					
		+ Notch1 + Notch2 + Notch3 all	auto off manual	1100.000 ... 1700.000 MHz	30 ... 1600 kHz					
snc gnc	setNtpClient getNtpClient	<i>Mode</i>	<i>Server (40)</i>							
		on <u>off</u>	<u>default</u>							
sntp gntp	setNTPServer getNTPServer	<i>Enable</i>								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		off on								
snmp gnmp	setNtripCasterMountPoints getNtripCasterMountPoints	MountPointID MountPointID	Enable	MPName (32)	ExtServer	UserName (20)	Password (40)	ClientAuth		
		+ MP1 + MP2 + MP3 all	off on		No Yes			none basic		
smpf gmpf	setNtripCasterMPFormat getNtripCasterMPFormat	MountPointID MountPointID	Format	ManualFt (30)	FtDetails (100)					
		+ MP1 + MP2 + MP3 all	RTCMv2 RTCMv3 CMR NMEA RAW manual							
sncs gncs	setNtripCasterSettings getNtripCasterSettings	Mode	Port	Identifier (100)	TlsPort					
		off on	0 ... 2101 ... 65535	default	0 ... 2102 ... 65535					
sncu gncu	setNtripCasterUsers getNtripCasterUsers	UserID UserID	UserName (20)	Password (40)	MountPoints	MaxClients				
		+ User1 + User2 + User3 + User4 + User5 all			none + MP1 + MP2 + MP3 all	1 ... 10				
snts gnts	setNtripSettings getNtripSettings	Cd Cd	Mode	Caster (40)	Port	UserName (20)	Password (40)	MountPoint (32)	Version	SendGGA
		+ NTR1 + NTR2 + NTR3 all	off Server Client		0 ... 2101 ... 65535				v1 v2	auto off sec1 sec5 sec10 sec60
Inst	IstNTRIPSourceTable	Caster (40)	Port							
			0 ... 2101 ... 65535							
sntt gnnt	setNtripTlsSettings getNtripTlsSettings	Cd Cd	Enable	Fingerprint (96)						
		+ NTR1 + NTR2 + NTR3 all	off on							
soc goc	setObserverComment getObserverComment	Comment (120)								
		Unknown								
sop gop	setObserverParameters getObserverParameters	Observer (20)	Agency (40)							
		Unknown	Unknown							
spe gpe	setPeriodicEcho getPeriodicEcho	Cd Cd	Message (201)	Interval						

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ COM1 + COM2 + COM3 all	<u>A:Unknown</u>	off once msec100 msec200 msec500 sec1 sec2 sec5 sec10 sec15 sec30 sec60 min2 min5 min10 min15 min30 min60						
spfw gpfw	setPortFirewall getPortFirewall	Interface <i>Interface</i>	<i>OpenPorts</i>	<i>PortList (100)</i>						
		+ Ethernet + WiFi + Cell all	none <u>default</u> all PortList							
spps gpps	setPPSPParameters getPPSPParameters	<i>Interval</i>	<i>Polarity</i>	<i>Delay</i>	<i>TimeScale</i>	<i>MaxSyncAge</i>	<i>PulseWidth</i>			
		off msec10 msec20 msec50 msec100 msec200 msec250 msec500 <u>sec1</u> sec2 sec4 sec5 sec10 sec30 sec60	<u>Low2High</u> <u>High2Low</u>	-1000000.00 ... <u>0.00</u> ...1000000.00 ns	<u>GPS</u> Galileo BeiDou GLONASS UTC RxClock	0 ... <u>60</u> ... 3600 s	0.001 ... <u>1.000</u> ...1000.000 ms			
spm gpm	setPVTMode getPVTMode	<i>Mode</i>	<i>RoverMode</i>	<i>RefPos</i>						
		Static <u>Rover</u>	+ <u>StandAlone</u> + <u>SBAS</u> + <u>DGPS</u> + <u>RTKFloat</u> + <u>RTKFixed</u> + RTK all	<u>auto</u> Geodetic1 Geodetic2 Geodetic3 Geodetic4 Geodetic5 Cartesian1 Cartesian2 Cartesian3 Cartesian4 Cartesian5						
srl grl	setRAIMLevels getRAIMLevels	<i>Mode</i>	<i>Pfa</i>	<i>Pmd</i>	<i>Reliability</i>					
		off <u>on</u>	-12 ... <u>4</u> ... -1	-12 ... <u>4</u> ... -1	-12 ... <u>3</u> ... -1					
grc	getReceiverCapabilities									
srd grd	setReceiverDynamics getReceiverDynamics	<i>Level</i>	<i>Motion</i>							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		Max High <u>Moderate</u> Low	Static Quasistatic Pedestrian <u>Automotive</u> RaceCar HeavyMachinery UAV Unlimited							
gri	getReceiverInterface	<i>Item</i>								
		+ RxName + SNMPLanguage + SNMPVersion all								
lrf	lstRecordedFile	Disk	FileName (60)							
		DSK1								
era gra	exeRegisteredApplications getRegisteredApplications	Cd <i>Cd</i>	Application (12)							
		+ COM1 + COM2 + COM3 + USB1 + USB2 + IP10 ... IP17 + BT01 + UHF1 all	<u>Unknown</u>							
erf grf	exeRemoveFile getRemoveFile	Disk	FileName (200)							
		DSK1	<u>none</u> all							
ernf grnf	exeResetNavFilter getResetNavFilter	Level								
		+ <u>PVT</u> + <u>AmbRTK</u> + <u>GNSSAttitude</u> + <u>AmbGNSSAttitude</u> all								
erst grst	exeResetReceiver getResetReceiver	Level	EraseMemory							
		Soft <u>Hard</u> Upgrade	<u>none</u> + Config + PVTData + SatData + Bluetooth + WiFiAccessPoints + HTTPSCertificate all							
srxl grxl	setRINEXLogging getRINEXLogging	Cd <i>Cd</i>	<i>FileDuration</i>	<i>ObsInterval</i>	<i>SignalTypes</i>	<i>ExtraObsTypes</i>	<i>RINEXVersion</i>	<i>MixedNav</i>		

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ <u>DSK1</u> all	<u>none</u> hour1 hour6 hour24 minute15	<u>sec1</u> sec2 sec5 sec10 sec15 sec30 sec60	none + <u>GPSL1CA</u> + <u>GPSL1PY</u> + <u>GPSL2PY</u> + <u>GPSL2C</u> + <u>GPSL5</u> + <u>GLOL1CA</u> + GLOL2P + <u>GLOL2CA</u> + <u>GALL1BC</u> + <u>GALE6BC</u> + <u>GALE5a</u> + <u>GALE5b</u> + <u>GALE5</u> + <u>GEOL1</u> + <u>GEOL5</u> + <u>BDSB1I</u> + <u>BDSB2I</u> + <u>BDSB3I</u> + <u>BDSB1C</u> + <u>BDSB2a</u> + <u>BDSB2b</u> + <u>QZSL1CA</u> + <u>QZSL2C</u> + <u>QZSL5</u> + <u>NAVICL5</u> all	<u>none</u> + Dx + Sx + Channel all	<u>v211</u> v304ShortName	off <u>on</u>		
sroa groa	setRoamingMode getRoamingMode	<i>Enable</i>								
		off <u>on</u>								
sr2c gr2c	setRTCMv2Compatibility getRTCMv2Compatibility	<i>PRCType</i>	<i>GLOToD</i>	<i>RTKVersion</i>						
		<u>Standard</u> GroupDelay	<u>Tk</u> Tb	v2.1 <u>v2.2orLater</u>						
sr2f gr2f	setRTCMv2Formatting getRTCMv2Formatting	<i>ReferenceID</i>	<i>GLOToD</i>							
		<u>0 ... 1023</u>	<u>Tk</u> Tb							
sr2i gr2i	setRTCMv2Interval getRTCMv2Interval	<i>Message</i> <i>Message</i>	<i>ZCount</i>							
		+ RTCM1 + RTCM3 + RTCM9 + RTCM16 + RTCM17 + RTCM22 + RTCM23 24 + RTCM31 + RTCM32 all	<u>1 ... 2 ... 1000</u>							
sr2b gr2b	setRTCMv2IntervalObs getRTCMv2IntervalObs	<i>Message</i> <i>Message</i>	<i>Interval</i>							
		+ RTCM18 19 + RTCM20 21 all	<u>1 ... 600 s</u>							
sr2m gr2m	setRTCMv2Message16 getRTCMv2Message16	<i>Message (90)</i>								
		<u>Unknown</u>								
sr2o gr2o	setRTCMv2Output getRTCMv2Output	<i>Cd</i> <i>Cd</i>	<i>Messages</i>							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ COM1 + COM2 + COM3 + USB1 + USB2 + IP10 ... IP17 + NTR1 + NTR2 + NTR3 + IPS1 + IPS2 + IPS3 + IPS4 + IPS5 + BT01 + UHF1 + IPR1 + IPR2 + IPR3 + IPR4 + IPR5 all	none + RTCM1 + RTCM3 + RTCM9 + RTCM16 + RTCM18 19 + RTCM20 21 + RTCM22 + RTCM23 24 + RTCM31 + RTCM32 + RTCM17 + DGPS + RTK all							
sr2u gr2u	setRTCMv2Usage getRTCMv2Usage	MsgUsage								
		none + RTCM1 + RTCM3 + RTCM9 + RTCM15 + RTCM18 19 + RTCM20 21 + RTCM22 + RTCM23 24 + RTCM31 + RTCM32 + RTCM34 + RTCM17 + RTCM59 all								
sr3t gr3t	setRTCMv3CRSTransfo getRTCMv3CRSTransfo	Mode	TargetName (32)							
		auto manual								
sr3d gr3d	setRTCMv3Delay getRTCMv3Delay	Delay								
		0.0 ... 600.0 s								
sr3f gr3f	setRTCMv3Formatting getRTCMv3Formatting	ReferenceID	MSMSignals	GL0L2	RxType (32)					

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		0 ... 4095	+GPSL1CA +GPSL1PY +GPSL2PY +GPSL2C +GPSL5 +GLOL1CA +GLOL2P +GLOL2CA +GALL1BC +GALE6BC +GALE5a +GALE5b +GALE5 +GEOL1 +GEOL5 +BDSB1I +BDSB2I +BDSB3I +BDSB1C +BDSB2a +BDSB2b +QZSL1CA +QZSL2C +QZSL5 +NAVICL5 all	L2CA L2P	default					
sr3i gr3i	setRTCMv3Interval getRTCMv3Interval	Message Message	Interval							
		+RTCM1001 2 +RTCM1003 4 +RTCM1005 6 +RTCM1007 8 +RTCM1009 10 +RTCM1011 12 +RTCM1013 +RTCM1019 +RTCM1020 +RTCM1029 +RTCM1033 +RTCM1042 +RTCM1044 +RTCM1045 +RTCM1046 +RTCM1230 +MSM1 ... MSM7 all	0.1 ... 1.0 ... 600.0 s							
sr3m gr3m	setRTCMv3Message1029 getRTCMv3Message1029	Message (120)								
		Unknown								
sr3o gr3o	setRTCMv3Output getRTCMv3Output	Cd Cd	Messages							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ COM1 + COM2 + COM3 + USB1 + USB2 + IP10 ... IP17 + NTR1 + NTR2 + NTR3 + IPS1 + IPS2 + IPS3 + IPS4 + IPS5 + BT01 + UHF1 + IPR1 + IPR2 + IPR3 + IPR4 + IPR5 all	none + RTCM1001 + RTCM1002 + RTCM1003 <u>+ RTCM1004</u> + RTCM1005 <u>+ RTCM1006</u> + RTCM1007 + RTCM1008 + RTCM1009 + RTCM1010 + RTCM1011 <u>+ RTCM1012</u> + RTCM1013 + RTCM1019 + RTCM1020 + RTCM1029 <u>+ RTCM1033</u> + RTCM1042 + RTCM1044 + RTCM1045 + RTCM1046 + RTCM1071 ... RTCM1077 + RTCM1081 ... RTCM1087 + RTCM1091 ... RTCM1097 + RTCM1101 ... RTCM1107 + RTCM1111 ... RTCM1117 + RTCM1121 ... RTCM1127 + RTCM1131 ... RTCM1137 <u>+ RTCM1230</u> + MSM1 + MSM2 + MSM3 + MSM4 + MSM5 + MSM6 + MSM7 all							
sr3u	setRTCMv3Usage	<i>MsgUsage</i>								
gr3u	getRTCMv3Usage									

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		none + RTCM1001 ... <u>RTCM1013</u> + RTCM1015 + RTCM1016 + RTCM1017 + RTCM1019 ... <u>RTCM1027</u> + RTCM1029 + RTCM1033 + RTCM1037 + RTCM1038 + RTCM1039 + RTCM1042 + RTCM1044 + RTCM1045 + RTCM1046 + RTCM1071 ... <u>RTCM1077</u> + RTCM1081 ... <u>RTCM1087</u> + RTCM1091 ... <u>RTCM1097</u> + RTCM1111 ... <u>RTCM1117</u> + RTCM1121 ... <u>RTCM1127</u> <u>RTCM1230</u> + MSM1 + MSM2 + MSM3 + MSM4 + MSM5 + MSM6 + MSM7 all								
sst	setSatelliteTracking	<i>Satellite</i>								
gst	getSatelliteTracking									
		none + <u>G01</u> ... <u>G32</u> + <u>R01</u> ... <u>R30</u> + <u>E01</u> ... <u>E36</u> + S120 ... S158 + <u>C01</u> ... <u>C37</u> + C38 ... C63 + <u>J01</u> ... <u>J07</u> + <u>I01</u> ... <u>I14</u> + GPS + GLONASS + GALILEO + SBAS + BEIDOU + QZSS + NAVIC all								
ssu	setSatelliteUsage	<i>Satellite</i>								
gsu	getSatelliteUsage									

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		none + <u>G01 ... G32</u> + <u>R01 ... R24</u> + R25 + R26 + R27 + R28 + R29 + R30 + <u>E01 ... E36</u> + S120 ... S158 + <u>C01 ... C63</u> + <u>J01 ... J07</u> + GPS + GLONASS + GALILEO + SBAS + BEIDOU + QZSS all								
ssbc gsbc	setSBASCORRECTIONS getSBASCORRECTIONS	<i>Satellite</i>	<i>SISMode</i>	<i>NavMode</i>	<i>DO229Version</i>					
		auto EGNOS WAAS MSAS GAGAN SDCM S120 ... S158	Test <u>Operational</u>	EnRoute PrecApp <u>MixedSystems</u>	auto DO229C					
ssgp gsgp	setSBFGROUPS getSBFGROUPS	Group <i>Group</i>	<i>Messages</i>							
		+ Group1 + Group2 + Group3 + Group4 all	none [SBF List] + Measurements + Meas3 + RawNavBits + GPS + GLO + GAL + GEO + BDS + QZS + PVTCart + PVTGeod + PVTEExtra + Attitude + Time + Events + DiffCorr + Status + LBand + Advanced + PostProcess + Rinex + RinexMeas3 + Support							
esoc gsoc	exeSBFOnce getSBFOnce	Cd	Messages							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		DSK1 COM1 COM2 COM3 USB1 USB2 IP10 ... IP17 NTR1 NTR2 NTR3 IPS1 IPS2 IPS3 IPS4 IPS5 BT01 UHF1 IPR1 IPR2 IPR3 IPR4 IPR5	[SBF List] + Measurements + Meas3 + GPS + GLO + GAL + GEO + BDS + QZS + PVTCart + PVTGeod + PVTEExtra + Attitude + Time + Status + LBand + UserGroups + Advanced + PostProcess + Rinex + RinexMeas3 + Support							
sso gso	setSBFOutput getSBFOutput	<i>Stream</i> <i>Stream</i>	<i>Cd</i>	<i>Messages</i>	<i>Interval</i>					
		+ Stream1 ... Stream10 + Res1 + Res2 + Res3 + Res4 all	<u>none</u> DSK1 COM1 COM2 COM3 USB1 USB2 IP10 ... IP17 NTR1 NTR2 NTR3 IPS1 IPS2 IPS3 IPS4 IPS5 BT01 UHF1 IPR1 IPR2 IPR3 IPR4 IPR5	<u>none</u> [SBF List] + Measurements + Meas3 + RawNavBits + GPS + GLO + GAL + GEO + BDS + QZS + PVTCart + PVTGeod + PVTEExtra + Attitude + Time + Event + DiffCorr + Status + LBand + UserGroups + Advanced + PostProcess + Rinex + RinexMeas3 + Support	<u>off</u> OnChange msec10 msec20 msec40 msec50 msec100 msec200 msec500 sec1 sec2 sec5 sec10 sec15 sec30 sec60 min2 min5 min10 min15 min30 min60					
snt gnt	setSignalTracking getSignalTracking	<i>Signal</i>								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ GPSL1CA + GPSL1PY + GPSL2PY + GPSL2C + GPSL5 + GLOL1CA + GLOL2P + GLOL2CA + GALL1BC + GALE6BC + GALE5a + GALE5b + GALE5 + GEOL1 + GEOL5 + BDSB1I + BDSB2I + BDSB3I + BDSB1C + BDSB2a + BDSB2b + QZSL1CA + QZSL2C + QZSL5 + QZSL6 + NAVICL5 + GPS + GLONASS + GALILEO + SBAS + BEIDOU + QZSS + NAVIC all								
snu	setSignalUsage	<i>PVT</i>	<i>NavData</i>							
gnu	getSignalUsage									
		+ GPSL1CA + GPSL1PY + GPSL2PY + GPSL2C + GPSL5 + GLOL1CA + GLOL2P + GLOL2CA + GALL1BC + GALE6BC + GALE5a + GALE5b + GALE5 + GEOL1 + GEOL5 + BDSB1I + BDSB2I + BDSB3I + BDSB1C + BDSB2a + BDSB2b + QZSL1CA + QZSL2C + QZSL5 + QZSL6 all	+ GPSL1CA + GPSL1PY + GPSL2PY + GPSL2C + GPSL5 + GLOL1CA + GLOL2P + GLOL2CA + GALL1BC + GALE6BC + GALE5a + GALE5b + GALE5 + GEOL1 + GEOL5 + BDSB1I + BDSB2I + BDSB3I + BDSB1C + BDSB2a + BDSB2b + QZSL1CA + QZSL2C + QZSL5 + QZSL6 all							
ssi	setSmoothingInterval	<i>Signal</i>	<i>Interval</i>	<i>Alignment</i>						
gsi	getSmoothingInterval									

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ GPSL1CA + GPSL2PY + GPSL2C + GPSL5 + GL0L1CA + GL0L2P + GL0L2CA + GALL1BC + GALE6BC + GALE5a + GALE5b + GALE5 + GEOL1 + GEOL5 + BDSB1I + BDSB2I + BDSB3I + BDSB1C + BDSB2a + BDSB2b + QZSL1CA + QZSL2C + QZSL5 + QZSL6 + NAVICL5 all	0 ... 1000 s	0 ... 1000 s						
sspc gspc	setStaticPosCartesian getStaticPosCartesian	Position Position	X	Y	Z	Datum				
		+ Cartesian1 + Cartesian2 + Cartesian3 + Cartesian4 + Cartesian5 all	-8000000.0000 ... 0.0000 ... 8000000.0000 m	-8000000.0000 ... 0.0000 ... 8000000.0000 m	-8000000.0000 ... 0.0000 ... 8000000.0000 m	WGS84 ETRS89 NAD83 NAD83_PA NAD83_MA GDA94 GDA2020 User1 User2 Other				
sspg gspg	setStaticPosGeodetic getStaticPosGeodetic	Position Position	Latitude	Longitude	Altitude	Datum				
		+ Geodetic1 + Geodetic2 + Geodetic3 + Geodetic4 + Geodetic5 all	-90.0000000000 ... 0.0000000000 ... 90.0000000000 deg	180.0000000000 ... 0.0000000000 ... 180.0000000000 deg	-1000.0000 ... 0.0000 ... 30000.0000 m	WGS84 ETRS89 NAD83 NAD83_PA NAD83_MA GDA94 GDA2020 User1 User2 Other				
sts gts	setTimingSystem getTimingSystem	System								
		Galileo GPS BeiDou auto								
stlp gtlp	setTrackingLoopParameters getTrackingLoopParameters	Signal Signal	DLLBandwidth	PLLBandwidth	MaxTpDLL	MaxTpPLL	Adaptive			

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ GPSL1CA + Reserved1 + Reserved2 + GPSL2C + GPSL5 + GLOL1CA + GLOL2P + GLOL2CA + GALL1BC + GALE6BC + GALE5a + GALE5b + GALE5 + GEOL1 + GEOL5 + BDSB1I + BDSB2I + BDSB3I + BDSB1C + BDSB2a + BDSB2b + QZSL1CA + QZSL2C + QZSL5 + Reserved3 + NAVICL5 all	0.01 ... 0.25 ... 5.00 Hz	1 ... 15 ... 100 Hz	1 ... 100 ... 500 ms	1 ... 10 ... 200 ms	off on			
stm gtm	setTroposphereModel getTroposphereModel	ZenithModel	MappingModel							
		off Saastamoinen MOPS	Niell MOPS							
stp gtp	setTroposphereParameters getTroposphereParameters	Temperature	Pressure	Humidity						
		-100.0 ... 15.0 ... 100.0 degC	800.00 ... 1013.25 ... 1500.00 hPa	0 ... 50 ... 100 %						
suhc guhc	setUHFChannelTable getUHFChannelTable	Channel Channel	Bandwidth	RxFreq	TxFreq					
		+ Ch01 ... Ch32 all	Hz12500 Hz25000	0.00000 ... 475.00000 MHz	0.00000 ... 475.00000 MHz					
suhm guhmm	setUHFMode getUHFMode	Cd Cd	Power	Mode						
		+ UHF1 all	off on	Receiver Transmitter						
suhp guhpp	setUHFProtocol getUHFProtocol	Cd Cd	Protocol	RadioLinkRate	FEC					
		+ UHF1 all	PCCGMSK PCC4FSK PCCFST SATEL TRIMTALK450S_P TRIMTALK450S_T	auto	off on					
suhr guhr	setUHFrxChannel getUHFrxChannel	Cd Cd	Channel	ManualBW	ManualFreq					
		+ UHF1 all	manual Ch01 Ch02 ... Ch32	Hz12500 Hz25000	410.00000 ... 475.00000 MHz					
suht guht	setUHFTxChannel getUHFTxChannel	Cd Cd	Channel	TxPower						

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ UHF1 all	<u>Ch01</u> Ch02 ... Ch32	<u>mW100</u> mW200 mW500 mW1000						
suoc guoc	setUMSDOnConnect getUMSDOnConnect	<i>Mode</i>								
		<u>off</u> on								
eunc gunc	exeUnblockCellular getUnblockCellular	<i>PUK (20)</i>	<i>PIN (20)</i>							
suia guia	setUSBInternetAccess getUSBInternetAccess	<i>Enable</i>								
		<u>off</u> on								
sual gual	setUserAccessLevel getUserAccessLevel	<i>UserID</i> <i>UserID</i>	<i>UserName (16)</i>	<i>Password (32)</i>	<i>UserLevel</i>	<i>SSHKey (232)</i>				
		+ User1 User8 all	...		Viewer <u>User</u>					
sud gud	setUserDatum getUserDatum	<i>Datum</i> <i>Datum</i>	<i>Tx</i>	<i>Ty</i>	<i>Tz</i>	<i>Rx</i>	<i>Ry</i>	<i>Rz</i>	<i>D</i>	
		+ User1 + User2 all	-2000000.00 ...0.00 ...2000000.00 mm	-2000000.00 ...0.00 ...2000000.00 mm	-2000000.00 ...0.00 ...2000000.00 mm	-100.0000 ...0.0000 ...100.0000 mas	-100.0000 ...0.0000 ...100.0000 mas	-100.0000 ...0.0000 ...100.0000 mas	-100.000000 ...0.000000 ...100.000000 ppb	
sudv gudv	setUserDatumVel getUserDatumVel	<i>Datum</i> <i>Datum</i>	<i>TxVel</i>	<i>TyVel</i>	<i>TzVel</i>	<i>RxVel</i>	<i>RyVel</i>	<i>RzVel</i>	<i>DVel</i>	<i>RefYear</i>
		+ User1 + User2 all	-2000.00 ...0.00 ...2000.00 mm/yr	-2000.00 ...0.00 ...2000.00 mm/yr	-2000.00 ...0.00 ...2000.00 mm/yr	-10.0000 ...0.0000 ...10.0000 mas/yr	-10.0000 ...0.0000 ...10.0000 mas/yr	-10.0000 ...0.0000 ...10.0000 mas/yr	-1.00000 ...0.00000 ...1.00000 ppb/yr	1900.00 ...2000.00 ...2100.00 yr
sue gue	setUserEllipsoid getUserEllipsoid	<i>Datum</i> <i>Datum</i>	<i>A</i>	<i>Invf</i>						
		+ User1 + User2 all	6300000.000 ...6378137.000 ...6400000.000 m	290.000000000 ...298.25722356 ...305.000000000						
swbi gwbi	setWBIMitigation getWBIMitigation	<i>Mode</i>								
		<u>off</u> on								
swfa gwfa	setWiFiAccessPoint getWiFiAccessPoint	<i>SSID (32)</i>	<i>EncryptionType</i>	<i>Key (40)</i>	<i>Channel</i>	<i>Hotspot</i>	<i>SSIDActual (32)</i>			
		default	none WPA2	<u>password</u>	1...6...11	<u>off</u> on	<u>model-sn</u>			
lwa	IstWiFiAccessPoints	<i>Type</i>								
		+ Known + Reachable all								
swfm gwfm	setWiFiMode getWiFiMode	<i>Enable</i>	<i>Mode</i>							
		<u>off</u> on	<u>AccessPoint</u> Client							

SBF List

ASCIIn	AttCovEuler	AttEuler
AuxAntPositions	BBSamples	BDSAlm
BDSIon	BDSNav	BDSRaw
BDSRawB1C	BDSRawB2a	BDSRawB2b
BDSUtc	BaseLine	BaseStation
BaseVectorCart	BaseVectorGeod	BluetoothStatus
CellularStatus	ChannelStatus	Commands
Comment	CosmosStatus	DOP
DiffCorrIn	DiskStatus	DynDNSStatus
EndOfAtt	EndOfMeas	EndOfPVT
ExtEvent	ExtEventAttEuler	ExtEventBaseVectGeod
ExtEventPVTCartesian	ExtEventPVTGeodetic	GALAlm
GALGstGps	GALLon	GALNav
GALRawCNAV	GALRawFNAV	GALRawINAV
GALSARRLM	GALUtc	GEOAlm
GEOClockEphCovMatrix	GEODegrFactors	GEOFastCorr
GEOFastCorrDegr	GEOIGPMask	GEOIntegrity
GEOlonoDelay	GEOLongTermCorr	GEOMT00
GEONav	GEONetworkTime	GEOPRNMask
GEORawL1	GEORawL5	GEOServiceLevel
GLOAlm	GLONav	GLORawCA
GLOTime	GPSAlm	GPSIon
GPSNav	GPSRawCA	GPSRawL2C
GPSRawL5	GPSUtc	Group1
Group2	Group3	Group4
IPStatus	InputLink	LBandBeams
LBandTrackerStatus	Meas3CN0HiRes	Meas3Doppler
Meas3MP	Meas3PP	Meas3Ranges
MeasEpoch	MeasExtra	NAVICRaw
NTRIPClientStatus	NTRIPServerStatus	OutputLink
PVTCartesian	PVTGeodetic	PVTSupport
PVTSupportA	PosCart	PosCovCartesian
PosCovGeodetic	PosLocal	PosProjected
QZSAlm	QZSNav	QZSRawL1CA
QZSRawL2C	QZSRawL5	QZSRawL6
QualityInd	RFStatus	RTCMDatum
ReceiverSetup	ReceiverStatus	ReceiverTime
RxComponents	RxMessage	SatVisibility
SystemInfo	UHFStatus	VelCovCartesian
VelCovGeodetic	WiFiAPStatus	WiFiClientStatus
xPPSOffset		